


PARTS EXPLOSION


CABINET ASSEMBLY




NOTE: Please reference the Manufacturer's Part Number when calling for Replacement Parts. For Parts under Warranty, the Serial Number of your machine is required.

PARTS EXPLOSION

MOTOR & BLOWER ASSEMBLY



CONTROL PANEL ASSEMBLY



NOTE: Please reference the Manufacturer's Part Number when calling for Replacement Parts. For Parts under Warranty, the Serial Number of your machine is required.

PARTS LIST

Key No.	Description	QTY	MFG. PART NO.
1	Cross Recessed Countersunk Head Screw M6x20	4	P62-450-1
2	Switch	1	P62-450-2
3	Flat Washer	8	P62-450-3
4	Spring Washer	8	P62-450-4
5	Cross Recessed Countersunk Head Screw M4X10	8	P62-450-5
6	Hex Nut	7	P62-450-6
7	Spring Washer	7	P62-450-7
8	Flat Washer	7	P62-450-8
9	Cross Recessed Countersunk Head Screw M5x16	13	P62-450-9
10	Mounted Plate	1	P62-450-10
11	Air Blower	1	P62-450-11
12	Hand Ring	4	P62-450-12
13	Hex Nut with Flange M6	4	P62-450-13
14	Hook Screw	4	P62-450-14
15	Key Chain	4	P62-450-15
16	Lifting Chain	4	P62-450-16
17	S-Hook	4	P62-450-17
18	Cross Recessed Countersunk Head Screw M6X16	4	P62-450-18
19	Frame	1	P62-450-19
20	Handle	1	P62-450-20
21	Protective Screening	1	P62-450-21
22	Big Washer	10	P62-450-22
23	Cross Recessed Pan Head Tapping Screw	10	P62-450-23
24	Plate Filter	1	P62-450-24
25	Bag Filter	1	P62-450-25
26	Filter Block Slice	2	P62-450-26
27	Baffle Base	2	P62-450-27
28	Self-Plugging Rivet	6	P62-450-28
29	Rubber Plug	4	P62-450-29
30	Panel Component	1	P62-450-30
31	Fixed Plate	1	P62-450-31
32	Locking Washer	1	P62-450-32
33	Cross Recessed Pan Head Tapping Screw	5	P62-450-33
34	Capacitor	1	P62-450-34
35	Remote Control	1	P62-450-35
36	Rubber Bushing	1	P62-450-36
37	Electrical Box	1	P62-450-37
38	Circuit Board	1	P62-450-38
39	Electrical Installation Board	1	P62-450-39
40	Wire Clip	1	P62-450-40
41	Fuse Holder	1	P62-450-41
42	Fuse	1	P62-450-42
43	Three - Wire Plug Cable	1	P62-450-43
44	Cross Recessed Pan Head Tapping Screw	6	P62-450-44
45	Ventilating Ring	2	P62-450-45
46	Left Turbine Cap	1	P62-450-46
47	Left Turbine Wheel	1	P62-450-47
48	Blower Housing	1	P62-450-48
49	Hex socket button head screw M6X10	3	P62-450-49
50	Spring washer	4	P62-450-50
51	Motor 120v	1	P62-450-51
52	Right Turbine Wheel	1	P62-450-52
53	Right Turbine Cap	1	P62-450-53